


Getting Started Guide

Aware Fitness Center Application

Doc Version v1.8
May 20, 2019



Process Overview:



Included in Shipment:


- Fitness Center Hub With Screen (connects sensors to Internet (via ethernet cable or Wifi) and power cable)
- Sensors (to attach to fitness center equipment)
- Zip Ties to affix sensors to equipment
- Getting Started Guide

Setup Instructions:

1) Hub Setup



- Plug the hub to power where you intend to install it, ensure that you have access to WiFi or an ethernet cable at that location and that it is not more than 50 feet away from the installation locations of the sensors.

When you first plug the hub into power you will see the following:



For a WiFi installation:

- On the Hub, touch the icon for the settings page and press the WiFi tab. Find your WiFi connection name (SSID), click it and enter your password when prompted. *Note: In the screenshots below we show the WiFi network called BuildingLink. Your network names will be different based on your installed WiFi network at your fitness center.*



- Check if the Hub connects to the WiFi (you should see a small pop up “WiFi Connected” coming from the bottom of the screen)

For a Ethernet installation:

- Connect the ethernet cable to the Hub and check if the Hub Status Icon on the screen turns to green after 1 min. *Note: The Hub requires a ethernet connection with DHCP (automatic assignment of IP address).*

2) Sensor Setup

- The sensors are preconfigured to the hub and setup on the Buildinglink server.
- Place the batteries into the sensors - make sure the batteries are placed positive to positive (correct orientation). They will automatically connect to the hub within one minute. The sensors blink green every 30 seconds when they are connected. If they blink red or not at all see troubleshooting below.
- Login to Buildinglink and go to the “Dashboard” (Manager Dashboard) page , you should see “Aware! Sensor Status”. Verify that the solution is active and ensure that all sensors are connected and reporting data.
- Troubleshooting: Check the Hub’s sensor count to ensure that all sensors are connected. If a sensor is not connected, check the battery, then go to the pairing screen and enter pairing mode. When in pairing mode, shake the sensor to be paired in order to pair it to the hub. See the pairing video at aware.buildinglink.com/fc. If you have any problems, contact us: aware@buildinglink.com

Please don’t forget to announce the solution to your club members!

